

→ Experiment Title

Study of LAN Topology, Network Devices, and Address Configuration.

→ Problem Statement

- 1) To Study the LAN topology used in College Campus.
- 2) To identify networking device & understand their function.
- 3) To analyze wired & wireless Communication method used in the network.
- 4) To measure speed of Network for wired & wireless connections.
- 5) To obtain MAC, IP Address & Subnet mask.

→ Draw & identify LAN topology of College Campus & clearly label all components such as router, switches & etc.

Solⁿ :- The College Campus network observed this study consists of :

- Layer-3 Core switches in the Server room.

- Managed by POE + Switches.
- Wireless Access point (APs)
- Ethernet port in classroom & Laboratories.

→ Network Topology

Hybrid Hierarchical Topology
Which Combines :

- 1) Tree Topology
- 2) Extended Star Topology
- 3) Ring Topology.

→ The Network hierarchical layer

- i) Core layer
- ii) Distribution layer
- iii) Access layer

→ • Core layer :-

Core layer contains Server Room and Server room have Firewall, Router, 2- L3+ Switches, Patch Rack, Server, inventory, etc.

• Distribution Layer :-

• Distribution layer contains 4-

- Switches .

- The 4 Switches are :-

- i) Main Build $\rightarrow$ R7 (Room no-213, 2nd Floor)
- ii) Main Build $\rightarrow$ R1 (Room no-301, 3rd Floor)
- iii) Main Build $\rightarrow$ R6 (Room no-113, 1st Floor).
- iv) Main Build $\rightarrow$ R2 (Room no-201, 2nd Floor).

- This 4 - Switches Contains $\rightarrow$

- ① 18 Port Gigabit Easy Smart Switch with 16 - Port . TL-SG1218MPE

- ② SG 3428 XMP $\rightarrow$ 24 Port Gigabit & 4-port 10 GE SFP+ , L2 + managed switches with 24 Port POE+ .

- Now Let's discuss these 2 above Component :-

① TP-Link TL-SG1218MPE

- Likely Used for : CCTV Cammera , wifi access point , etc .
- 18 Port Gigabit " Easy Smart " Switch .
- 16 Port Support POE+


② TP-Link Omada SG3428 XMP

- Higher-end managed Layer 2 + Switch.
- 24 PoE + Port, uplinks, 10G SFP
- Usually acts as a main distribution for each floor.


→ Access Layer

- Access layer contain 3 - Switches i.e.
 - 1) Main Build R1 - [Room no - 301, 3rd Floor].
 - 2) Main Build R4 - [Room no - 05, Ground "].
 - 3) Main Build R5 - [Room no - 18, Ground Floor].
- Every switches act as access layer which helps to provide network connectivity to all classroom, Lab, Faculty Room, etc.
- Access Layer directly Connect:
 - 1) Ethernet Port
 - 2) Wireless AP
 - 3) Lab System
 - 4) Outdoor Wireless AP (ex - 018)

→ Server Room Architecture / Topology



Topology




→ R1, R7, R2, R6 → Distribution layer

→ Server room → Core layer

→ R1, R2, R3, R4, R5, R6, R7 → Access layer

Access Layer Switch (3rd Floor - 301)



Windows PowerShell
Copyright (C) Microsoft Corporation. All rights reserved.

Install the latest PowerShell for new features and improvements! <https://aka.ms/PSWindows>

PS C:\Users\ADMIN> ipconfig

Windows IP Configuration

Ethernet adapter Ethernet:

Media State : Media disconnected
Connection-specific DNS Suffix . : hgu_lan

Ethernet adapter Ethernet 2:

Connection-specific DNS Suffix . :
Link-local IPv6 Address : fe80::992c:6cd2:c438:a76c%8
IPv4 Address. : 192.168.56.1
Subnet Mask : 255.255.255.0
Default Gateway :

Wireless LAN adapter Local Area Connection* 9:

Media State : Media disconnected
Connection-specific DNS Suffix . :

Wireless LAN adapter Local Area Connection* 10:

Media State : Media disconnected
Connection-specific DNS Suffix . :

Wireless LAN adapter Wi-Fi:

Connection-specific DNS Suffix . :
IPv6 Address. : 2401:4900:7724:848f:bc56:1acc:5293:d899
Temporary IPv6 Address. : 2401:4900:7724:848f:d9ca:8701:255f:333d
Link-local IPv6 Address : fe80::ec27:de91:8697:173c%5
IPv4 Address. : 10.240.176.129
Subnet Mask : 255.255.255.0
Default Gateway : fe80::105e:c4ff:fec4:afac%5
10.240.176.182

WIRELESS CONNECTION

PS C:\Users\ADMIN> |  Using "ipconfig"


```
PS C:\Users\ADMIN> ipconfig
```

Windows IP Configuration

Ethernet adapter Ethernet 2:

```
Connection-specific DNS Suffix . :  
Link-local IPv6 Address . . . . . : fe80::992c:6cd2:c438:a76c%8  
IPv4 Address. . . . . : 192.168.56.1  
Subnet Mask . . . . . : 255.255.255.0  
Default Gateway . . . . . :
```

Wireless LAN adapter Local Area Connection* 9:

```
Media State . . . . . : Media disconnected  
Connection-specific DNS Suffix . :
```

Wireless LAN adapter Local Area Connection* 10:

```
Media State . . . . . : Media disconnected  
Connection-specific DNS Suffix . :
```

Ethernet adapter Ethernet:

```
Connection-specific DNS Suffix . :  
Link-local IPv6 Address . . . . . : fe80::3e84:595f:7e3a:56c9%15  
IPv4 Address. . . . . : 10.85.19.63  
Subnet Mask . . . . . : 255.255.248.0  
Default Gateway . . . . . : 10.85.16.1
```

Wireless LAN adapter Wi-Fi:

```
Media State . . . . . : Media disconnected  
Connection-specific DNS Suffix . :
```

```
PS C:\Users\ADMIN> | → Using IPCONFIG
```

WIRED CONNECTION

WIRELESS SPEED

Performance

CPU

5% 0.81 GHz

Memory

5.8/7.8 GB (74%)

Disk 0 (C:)

SSD
0%

Ethernet

Ethernet 2
S: 0 R: 0 Kbps

Wi-Fi

Wi-Fi
S: 0 R: 0 Kbps

GPU 0

Intel(R) HD Graphics 6...
1%


Wi-Fi

Throughput

Intel(R) Dual Band Wireless-AC 8265

5 Mbps

3.6 Mbps



Send

0 Kbps

Receive

0 Kbps

Adapter name: Wi-Fi

SSID: Galaxy A038755

Connection type: 802.11n

IPv4 address: 10.81.18.68

IPv6 address: 2409:408a:1cc4:21b2:d49c:34a5:75bb:69af

Signal strength:

↳ MAC A

Windows PowerShell

X + v

Windows PowerShell

Copyright (C) Microsoft Corporation. All rights reserved.

Install the latest PowerShell for new features and improvements! <https://aka.ms/PSWindows>

PS C:\Users\ADMIN> getmac

Physical Address	Transport Name
B0-0C-D1-2C-3A-DF	Media disconnected
0E-6B-7F-E1-99-D2	\Device\Tcpip_{27635621-3133-4B8B-9255-E7C4BB9E0EA7}
0A-00-27-00-00-08	\Device\Tcpip_{3F28BB86-23C7-4F82-8497-6D44C1776D07}

PS C:\Users\ADMIN> |

→ MAC ADDRESS

→ Using "getmac"

→ Difference b/w wired & wireless speed?

Solⁿ

<u>Wired Network</u>	<u>Wireless Network</u>
i) Faster Communication	i) Slower Communication
ii) Suitable for tasks requiring high bandwidth	ii) Suitable for mobile devices and general usage.
iii) Low latency	iii) Higher latency
iv) Stable Connection	iv) Affected by distance/interference.
v) Dedicated physical medium	v) Shared radio medium.

• Conclusion

Wired Connections are faster and more flexible while wireless connections offer flexibility and easy to use.

→ Role of Subnet mask in network

- A Subnet mask plays an important role in network communication.

- It divides an IP address in network part and host part.
- Helps in identifying whether a device belongs to the same network or not.
- Enables efficient routing of data within a network.
- Reduces network congestion by organizing devices into subnets.

Example

If the IP Address is $192.168.1.5$ and Subnet mask is $255.255.255.0$,

- Network portion $\rightarrow 192.168.1$
- Host portion $\rightarrow 5$

Conclusion :

The analysis shows that while wired network provide better speed and stability, wireless networks are more convenient. Additionally Subnet masks are crucial for efficient data transmission and network management.